

DUM

**installing soft seats
beech sticks
beech stool**

- set allen wrench
- 6 mm wood drill

DUM



the holes have been pre-drilled



drill through with a 6 mm wood drill



the soft pad has inserts



mount the pads on the seat with the bolts