



INSTRUCTIONS - ENGLISH

Electrical installation works should be carried out by licenced electricians.

1. Check content.
2. Feed the cable through all holes. Then, insert the powerdot (A) through the bracket (B) and distancing nut (C).
3. Mount the powerdot nut (D) until it is thoroughly tightened to the distancing nut. Test it assembly by shaking it. If it rattles, then the powerdot is not fully tightened.
4. Using the 6 screws (4x16 mm), mount the assembled bracket with all components to the underside of the Beech Private.
5. We recommend a distance of 20 cm measured from the side and 3 cm inwards.
6. Once all steps are completed, route the cables appropriately for the intended usage and connect the plug to a socket.

INSTRUCTIES - NEDERLANDS

Elektrische installatiewerkzaamheden moeten worden uitgevoerd door erkende installateurs.

1. Controleer de inhoud.
2. Leid de kabel door alle gaten. Steek vervolgens de powerdot (A) door de beugel (B) en de afstandsbuis (C).
3. Monteer de powerdot-moer (D) totdat deze goed vastzit op de afstandsbuis. Test het geheel door het te schudden. Als het rammelt, dan is de powerdot onjuist vastgedraaid.
4. Monteer met behulp van de 6 schroeven (4x16 mm) de gemonteerde beugel met alle onderdelen aan de onderzijde van de Beech Private.
5. Wij adviseren een afstand van 20 cm vanaf de zijkant gemeten.
6. Nadat alle stappen zijn voltooid, leidt u de kabels op de juiste manier voor het beoogde gebruik en sluit u de stekker aan op een stopcontact.